

High-end Converter

M-1620 Pro

MADI | AVB

16-Channel A/D, 20-Channel D/A Converter
with Milan®, MADI and ADAT®



User's Guide

RME

RME M-1620 Pro User's Guide

Table of Contents

| | |
|---|----|
| 1. Safety Precautions | 4 |
| 2. Introduction | 5 |
| 2.1. About This Manual | 5 |
| 2.2. Firmware Update | 5 |
| 2.3. Use of the Display and Encoder | 6 |
| 2.3.1. Sections | 6 |
| 2.3.2. Tabs | 7 |
| 2.4. Status Indicator Color Chart | 7 |
| 3. Hardware | 8 |
| 3.1. Hardware Specifications | 9 |
| 3.2. Package Contents | 9 |
| 3.3. Power On | 9 |
| 3.4. Standby Switch | 10 |
| 3.5. Ring Illumination | 10 |
| 3.6. Headphone Outputs | 11 |
| 3.7. Phones Specifications | 11 |
| 3.8. Control Section | 11 |
| 3.9. Power Supplies | 12 |
| 3.10. Analog Line Input Connectors | 12 |
| 3.11. AD Converter Specifications | 13 |
| 3.12. Analog Line Output Connectors | 13 |
| 3.13. DA Converter Specifications | 14 |
| 3.14. Analog Line Levels | 14 |
| 3.15. MADI Coaxial and SFP | 14 |
| 3.16. ADAT Inputs and Outputs | 15 |
| 3.17. Network Connection | 16 |
| 3.18. Word Clock | 17 |
| 3.19. USB 2.0 Type B Jack | 17 |
| 3.20. Mounting the Rack Adapter Brackets | 18 |
| 4. Accessories | 19 |
| 5. MILAN® AVB Connectivity | 20 |
| 5.1. Identifying a Device Remotely | 20 |
| 5.2. Changing the Device Name | 21 |
| 5.3. AVB Stream Size and Format | 21 |
| 5.4. AVB Network Latency | 22 |
| 6. Quick Start (MADI) | 23 |
| 7. Warranty and Support | 25 |
| 7.1. Warranty | 25 |
| 7.2. Support | 25 |
| 7.3. Support Contacts | 26 |
| 8. STATE Section | 27 |
| 8.1. Power State | 27 |
| 8.1.1. Notification of Single Power Failure | 27 |

| | |
|---|----|
| 8.2. Presets | 28 |
| 8.2.1. Saving Presets | 28 |
| 8.2.2. Loading Presets | 29 |
| 8.2.3. Loading Factory Default Settings | 30 |
| 8.3. Device Lock | 30 |
| 8.3.1. Locking the Device | 30 |
| 8.3.2. Unlocking the Device | 31 |
| 8.4. Front Panel Illumination | 31 |
| 8.4.1. Dark Mode | 32 |
| 8.4.2. Changing the Meters to Peak or RMS Mode | 33 |
| 8.4.3. Persistent Clipping Notifications and Peak Hold | 34 |
| 8.4.4. Metering of Digital Signals | 35 |
| 8.5. Remote Control Overview | 35 |
| 8.5.1. Finding the Device on a Network | 35 |
| 8.5.2. Assigning a Static IP Address | 37 |
| 8.5.3. Web Remote | 37 |
| 8.5.4. JSON(OSC) Remote Control | 38 |
| 8.5.5. JSON(OSC) Implementation Chart | 40 |
| 8.6. Monitor Fan Speed and Temperature | 40 |
| 8.6.1. Adjust Fan Profile | 40 |
| 8.7. Anti-Aliasing Filter | 41 |
| 8.7.1. Changing the Aliasing Filter | 41 |
| 8.8. Device Information | 42 |
| 9. INPUT Section | 44 |
| 9.1. Analog Inputs | 44 |
| 9.1.1. Adjusting the Input Line Level | 44 |
| 9.2. MADI Inputs | 45 |
| 9.2.1. MADI at High Sample Rates | 45 |
| 9.2.2. Connecting Two Identical MADI Signals for Redundancy | 46 |
| 9.3. AVB Input Streams | 47 |
| 9.3.1. Change AVB Input Stream Size | 47 |
| 9.4. ADAT Inputs | 49 |
| 10. OUTPUT Section | 50 |
| 10.1. Routing Signals to the Outputs | 50 |
| 10.2. Analog Outputs | 51 |
| 10.2.1. Adjusting the Output Line Level | 51 |
| 10.2.2. Mute Analog Outputs | 52 |
| 10.2.3. Phones Out | 53 |
| 10.2.4. Adjusting the Headphone Volume | 53 |
| 10.2.5. Muting the Phones Output | 54 |
| 10.2.6. Using Phones Out as a Balanced Line Output | 54 |
| 10.3. MADI Outputs | 55 |
| 10.3.1. Setting the Output Channel Format and Frame Pattern | 55 |
| 10.3.2. MADI Daisy Chains | 56 |
| 10.3.3. MADI Port Mirroring | 56 |
| 10.4. AVB Output Streams | 56 |
| 10.4.1. Change AVB Output Stream Size and Format | 57 |
| 10.4.2. Adjusting the Network Latency | 58 |

| | |
|--|----|
| 10.5. ADAT Outputs | 58 |
| 11. CLOCK Section | 60 |
| 11.1. Clock Status | 60 |
| 11.2. Clock Reference | 60 |
| 11.2.1. Selecting a Clock Reference | 62 |
| 11.3. Sample Rates Overview | 62 |
| 11.3.1. Following an External Clock Reference | 62 |
| 11.3.2. Number of Channels | 64 |
| 11.3.3. Selecting a Sample Rate | 64 |
| 11.3.4. Effects of Sample Rate Changes on Existing Routing | 65 |
| 11.4. Set Word Clock Output to Single Speed | 65 |
| 12. Annex | 66 |
| 12.1. Glossary | 67 |
| 12.2. Regulatory Compliance | 68 |
| 12.2.1. CE Compliance | 68 |
| 12.2.2. FCC Compliance | 68 |
| 12.2.3. Note on Disposal | 68 |

⚠ WARNING**DO NOT OPEN DEVICE - RISK OF ELECTRIC SHOCK**

The unit has non-isolated live parts inside. No user serviceable parts inside. Refer service to qualified service personnel.

⚠ CAUTION**General Safety Information**

Read read the following safety information thoroughly and keep it in a safe place for later reference.

KEEP AWAY FROM WATER AND MOISTURE

Prevent moisture and water from entering the device. Never leave objects containing liquid on top or near the device. Do not use this product near water, i. e. swimming pool, bathtub or wet basement. Danger of condensation inside - do not turn on before the device has reached room temperature.

ENSURE PROPER VENTILATION

Do not cover the vents on the side of the unit. Ensure proper ventilation to avoid overheating. The maximum ambient operating temperature of the device is 35° C (95° F).

MAINS

The apparatus shall be connected to a mains socket outlet with a protective earthing connection. Do not use defective power cords. Ensure that the AC socket outlet for the device or an external power supply is easily accessible.

Operation of the device is limited to the description in this manual.

NOTICE**Read the User Manual**

Please read this manual completely before using the product. It includes all information necessary to use and operate this device.

2. Introduction

Thank you for purchasing the M-1620 Pro.

The **M-1620 Pro** is a versatile multichannel format converter with exceptional audio quality across each of its channels. State-of-the-art components from audiophile grade converters have been carefully aligned to fit into a compact, 1 HU 19" rack device.

The device was designed to use the entire front for visual feedback on its state and configuration. A display with encoder gives access to all configuration options directly at the device. Two headphone outputs at the front can receive any signal connected to the device, whether analog or digital. The analog I/O at the back are accessible via D-Sub 25 connectors.

Each analog channel can be individually adjusted to three different sensitivities that are perfectly matched to the converter's range. While this is usually implemented with digital 'trims', the M-1620 Pro does the adjustment in the analog domain, ensuring that the converter's signal to noise ratio is not reduced when adapting to common line levels.

Digital audio can be received, routed, and sent over MADI and MILAN®-certified AVB. While MADI remains the de-facto standard of point-to-point audio transmission, MILAN has been chosen as a robust network solution based on open standards. It supports sending and receiving of up to 128 audio channels over a single network cable.

Various remote control protocols allow the device to be configured seamlessly via IEEE 1722.1 ATDECC, a JSON OSC API, and a web interface accessible by network or USB connection with a browser.

The coaxial MADI port and a slot for a second, independent or redundant optical MADI port (SFP module) can be used for daisy chaining, merging and converting MADI signals with lowest latencies.

2.1. About This Manual

This document was created for firmware **3.0.7** on **2025-06-24**. For an updated firmware, please check <https://www.rme-audio.com>.

Features described in this manual can change, for example when the device firmware is updated. It is therefore recommended to refer to the latest version of the manual available online.

<https://docs.rme-audio.com/m1620>

The following manual provides a detailed explanation of features and their proper use. Please read the safety instructions carefully.

Although the contents of this manual have been thoroughly checked for errors, RME can not guarantee that it is correct throughout. RME does not accept responsibility for any misleading or incorrect information within this guide. RME reserves the right to change specifications at any time without notice.

2.2. Firmware Update

New and improved features for this device, as well as bug fixes, are published on the RME website in the download section as a firmware update. The update is provided as a compressed file with a **.swu** extension and can be uploaded via web remote over USB or network.

To update the M-1620 Pro:

1. Connect the device by USB or network cable and open the Web Remote.

See: [Section 8.5.1, "Finding the Device on a Network"](#)


2. Download the current firmware from the RME website.
3. Unpack the compressed file.
4. Open the **Settings** in the Web Remote.
5. Within the **Firmware Update** section, press the **Select .swu Firmware File** button and locate the unpacked file.
6. Press **Start Firmware Update**.



The unit retains all settings, including presets, when the firmware is upgraded.

2.3. Use of the Display and Encoder

The M-1620 Pro can be controlled directly at the unit. For this purpose, a display and an encoder provide access to all features.




- Rotating the encoder when the standby screen is shown highlights one of four sections.
- Pushing the encoder when the screen is idle activates the previously active tab.
- Pushing the encoder when a section is highlighted opens the corresponding section.

2.3.1. Sections

All control items are categorized into four sections:

- **STATE** for general settings
- **INPUT** for audio input related settings
- **OUTPUT** for audio output related settings and routing
- **CLOCK** for digital clock related settings




To access the *INPUT* section:

1. Rotate the encoder to highlight the "STATE" section
2. Rotate the encoder to highlight the "INPUT" section
3. Push the encoder to open the "INPUT" section.

2.3.2. Tabs

The **STATE**, **INPUT** and **OUTPUT** sections are further divided into **tabs**, which are shown when the section is opened. Upon opening one of the four sections, a white cursor with a surrounding blue line is shown to navigate between tabs and settings.



To close the section, move the cursor onto the minimize-icon  and confirm by pressing the encoder.


2.4. Status Indicator Color Chart

Notifications on this device have been optimized for different screen sizes. They are unified across the device display and the web remote and include a color bar that indicates the current state at a glance.

The following table shows the possible status indicator colors for reference.

| Status | Color | Description |
|----------------------|------------------|--|
| Warning | red | Requires a configuration change or matching external signal. |
| Notice | yellow | There is a potential issue. |
| Notice (in progress) | yellow with dots | There is a temporary issue that should resolve automatically. |
| No Routing | light green | <i>In output section:</i> Output is sending an empty signal. |
| Issues with Input | light green | <i>On standby screen in output section:</i> Output is working, but there are issues with the input signal. |
| Good | green | Working normally, no issues detected. |
| Inactive | grey | Feature is not monitored or disabled. |

3. Hardware



- | | |
|-----------|---|
| 1 | Section 3.4, “Standby Switch” |
| 2 | Section 3.6, “Headphone Outputs” |
| 3 | Section 3.8, “Control Section” |
| 4 | Section 3.18, “Word Clock” |
| 5 | Section 3.16, “ADAT Inputs and Outputs” |
| 6 | Section 3.15, “MADI Coaxial and SFP” |
| 7 | Section 3.12, “Analog Line Output Connectors” |
| 8 | Section 3.10, “Analog Line Input Connectors” |
| 9 | Section 3.17, “Network Connection” |
| 10 | MADI SFP Option |
| 11 | Section 3.19, “USB 2.0 Type B Jack” |
| 12 | Section 3.9, “Power Supplies” |

3.1. Hardware Specifications

| | RME M-1620 Pro |
|-------------------|--|
| EAN | 42 6012336 355 0 |
| Dimensions | 440 x 44 x 243 mm (17.3 x 1.7 x 9.6 inches) |
| Weight | 2.8 kg (6.2 lbs) |
| Package | 560 x 315 x 115 mm (22.1 x 12.4 x 4.5 inches) |
| Conformity | CE, FCC, WEEE, RoHS |
| Power supplies | 45 W 100-240 V AC, Optional external 12 V DC 3 A |
| Power consumption | typ. 30W, standby 0.5W |

3.2. Package Contents

The package of the M-1620 Pro contains the following items:

- M-1620 Pro
- two rack mount brackets
- four screws for rack mount brackets
- one power cord
- printed manual



If any item is missing from a factory-sealed package, please contact [your support](#) immediately.

3.3. Power On

The M-1620 Pro has a power off switch at the rear and a standby switch at the front.


Perform the following steps to power on the M-1620 Pro:

1. Ensure either or both power inlets are properly connected to a power source.
2. Toggle the mains switch at the back of the device to position **I** (*down*). The power indicator will light up in red (Standby) or white (On). This depends on the state of the device before the rear switch was toggled or the power cord removed.
3. If the device is in standby mode, push the standby switch to boot the device.



The M-1620 Pro features a [dark mode](#) which deactivates some or all lights of the front panel. This can be used to let the device appear powered off when it is in fact powered on. A short push on the standby switch or the the encoder deactivates this mode temporarily.

3.4. Standby Switch



The standby switch is used to power off the device when it is not in use. While in standby mode, the device is completely powered down except for a red ring illumination. No signals are processed or passed on.

Possible actions:



- When the device is in standby mode, a short push on the standby switch boots the device.
- When the device is powered on, push and hold the standby switch for several seconds in order to power down the device.

3.5. Ring Illumination

The following illumination patterns are possible:

No illumination



- There is no power at either of the two AC inlets.
- The power switch at the rear of the device is set to 'Off'.
- **Dark mode** has been activated.

Permanent red illumination



- The device is **powered off** but is receiving power at either one of the AC inlets.

Permanent white illumination



- The device is **powered on** and all systems are working without warning.

Alternating red/white illumination



- Something is not working properly. This is triggered when one of the four display sections: **STATE, INPUT, OUTPUT, or CLOCK** shows a **warning**.

3.6. Headphone Outputs

The M-1620 Pro features two headphone outputs, 1/4" (6.3mm) TRS, on the front panel. They can also function as a dual mono unbalanced outputs with individual routing and gain control and as a mono balanced line level outputs. Any digital or analog input signal can be monitored.



- ! Do not use TS (Mono, unbalanced) connectors at this output.
- ! When using "balanced" mode, the output signal increases by 6.02 dB.


3.7. Phones Specifications

Phones 1/2, 3/4:

- Resolution: 24 Bit
- Output: 6.3 mm TRS stereo (unbalanced) or mono (balanced) jack
- Maximum output level +4 dBu / +19 dBu (+10 dBu / +25 dBu in balanced mode)
- Output level switchable separately for each TRS connector
- Signal to Noise Ratio (SNR) @ 19 dBu: > 109 dB RMS unweighted, > 111 dB(A)
- Frequency response @ 44.1 kHz, -0.1 dB: 0 Hz – 20.0 kHz (Sharp Filter, default)
- Frequency response @ 96 kHz, -0.1 dB: 0 Hz – 20.0 kHz (Slow Filter, default)
- Frequency response @ 96 kHz, -0.1 dB: 0 Hz – 44.3 kHz (Sharp Filter)
- Frequency response @ 192 kHz, -0.1 dB: 0 Hz – 43 kHz (Slow Filter, default)
- Frequency response @ 192 kHz, -0.1 dB: 0 Hz – 85 kHz (Sharp Filter)
- THD+N @ 4 dBu, 32 Ohms load: < -100 dB, < 0.001 %
- THD+N @ 19 dBu, 100 Ohms load: < -100 dB, < 0.001 %

3.8. Control Section

The M-1620 Pro can be configured at the device.



To do so, the TFT display shows a menu. The adjacent encoder knob is used to navigate and change settings.



The encoder can be **pushed** in order to activate an item,




and **rotated** left and right in order to select an item.



If the device is powered on but the display shows no content, **dark mode** may be active. Rotate the encoder to temporarily bypass this mode and show the display.

3.9. Power Supplies

The M-1620 Pro has an internal power supply (PSU) that is connected via an IEC C14 inlet labeled "PSU" at the rear of the device. It is a high performance switch mode power supply that accepts 100V to 240V AC. It is short-circuit-proof, has an integrated line-filter, is fully regulated against voltage fluctuations, and suppresses mains interference.




The **power switch** next to the inlet internally disconnects the line and neutral connection to the internal power supply. Ground will remain connected.

12 V DC inlet

An optional external power supply can be connected instead of - or in addition to - the internal power supply. Redundancy is established when both inlets are connected to a power source. Additionally, both inlets are internally monitored. The M-1620 Pro can warn when one of the inlets receives no power.

The power supply must be capable of delivering 3 A at 12 V DC and connect with a type A (IEC 60130-10) plug (5.5 mm outer diameter, 2.1 mm inner diameter, positive polarity, optional lock tab).

3.10. Analog Line Input Connectors



The rear of the M-1620 Pro features two 25-pin D-sub connectors labeled "LINE IN" with Tascam® pinout.

These analog inputs are servo-balanced, allowing balanced and unbalanced signals to be connected without a difference in level.




When using unbalanced connections, be sure to connect pin 3 (negative/"cold") to pin 1 (ground), to avoid noise from the unconnected pin 3 input.

3.11. AD Converter Specifications

Line In 1-16:

- Resolution: 24 bit
- Input level switchable per channel +24 dBu, +19 dBu, +13 dBu @ 0 dBFS
- Inputs AC coupled, fully symmetrical signal path (servo-balanced)
- Input Impedance 9.5 kΩ
- Signal to Noise ratio (SNR) @ +24 dBu, 44.1 kHz: 117.0 dB RMS unweighted, 120.7 dBA
- Signal to Noise ratio (SNR) @ +19 dBu: 116.3 dB RMS unweighted, 119.9 dBA
- Signal to Noise ratio (SNR) @ +13 dBu: 114.7 dB RMS unweighted, 118.3 dBA
- Frequency response @ 44.1 kHz, -0.1 dB: 5 Hz – 20.5 kHz
- THD @ -1 dBFS: < -111 dB, < 0.00029%
- THD+N @ -1 dBFS: < -108 dB, < 0.00039 %
- Channel separation: > 110 dB

3.12. Analog Line Output Connectors



The rear of the M-1620 Pro features two 25-pin D-sub connectors labeled "LINE OUT" with Tascam® pinout.



The short circuit protected, low impedance balanced line outputs at the D-Sub

connectors do not operate servo balanced. When connecting unbalanced equipment, make sure pin 3 ("cold") of the output is not connected. A connection to ground may cause a decreased THD (higher distortion) and increased power consumption!

3.13. DA Converter Specifications

Line Out 1-16:

- Resolution: 24 bit
- Output level switchable per channel +24 dBu, +19 dBu, +13 dBu @ 0 dBFS
- Outputs DC coupled, fully symmetrical signal path ("truly balanced")
- Output impedance: 200 Ohm balanced, 100 Ohm unbalanced
- Signal to Noise Ratio (SNR) @ 13 dBu: 119.2 dB RMS unweighted
- Signal to Noise Ratio (SNR) @ 19 dBu: 119.7 dB RMS unweighted
- Signal to Noise Ratio (SNR) @ 24 dBu: 119.9 dB RMS unweighted
- Frequency response @ 44.1 kHz, -0.1 dB: 0 Hz – 20.3 kHz (Sharp Filter, default)
- Frequency response @ 96 kHz, -0.1 dB: 0 Hz – 30 kHz (Slow Filter, default)
- Frequency response @ 96 kHz, -0.1 dB: 0 Hz – 44.1 kHz (Sharp Filter)
- Frequency response @ 192 kHz, -0.1 dB: 0 Hz – 60.5 kHz (Slow Filter, default)
- Frequency response @ 192 kHz, -0.1 dB: 0 Hz – 85 kHz (Sharp Filter)
- THD @ 19 dBu: < -120 dB, < 0.0001 %
- THD+N @ 19 dBu: < -113 dB, < 0.0002 %
- Channel separation: > 110 dB

3.14. Analog Line Levels

The M-1620 Pro can be adjusted to the following reference levels:


| Reference | 0 dBFS | Headroom at +4dBu | Other RME devices |
|-----------|---------|-------------------|-------------------|
| +24 | +24 dBu | 20 dB | - |
| +19 | +19 dBu | 15 dB | LoGain |
| +13 | +13 dBu | 9 dB | +4 dBu |



When set to +24, analog outputs comply with **RP 155:2014 - SMPTE Recommended Practice**.

3.15. MADI Coaxial and SFP

The rear of the M-1620 Pro features coaxial and SFP MADI (AES10-2003) I/O.



Each input receives up to 64 audio channels. **Auto Input** (see [Section 9.2.2, “Connecting Two Identical MADI Signals for Redundancy”](#)) can be activated to treat both inputs as one.

The coaxial BNC connector accepts coaxial cables with 75 Ω impedance.

The "small form-factor pluggable" connector (**SFP**) accepts 125 MBit/s transceivers with LC connectors, 1310nm wavelength and multi-mode (MM) or single-mode (SM) cable support. These must be purchased separately (see [Section 4, “Accessories”](#)).

An SFP module has indicators to distinguish transmitter (▼) and receiver (▲). It can be inserted and removed while the device is powered on (hot plugging). Any plugged in connector must be removed before unlocking the SFP. Unlock and remove by pulling its integrated wire latch outward.



The wire latch of the SFP module is color coded. Black stands for the most common multimode module, blue stands for single mode which allows longer distance transmissions. It is possible, but not reliable to connect single mode transceivers with multi mode transceivers. Avoid this by always confirming that connected devices match the specification of the fiber optic cable.

On the device, the characteristics and state of the signal at either input can be inspected in the [INPUT section](#).


The presence or loss of a signal at either port is indicated on the standby screen and main menu if

- the input port is selected as **clock master**, or
- its audio channels are routed in the **OUTPUT** section.

When using the web remote, the characteristics and state of the signal at either input can be inspected in the [CLOCK section](#).

3.16. ADAT Inputs and Outputs

Four ADAT inputs and four outputs can be found at the rear of the device.




Each port can send up to eight audio channels. At double and quad speed, the maximum of channels per port is reduced to four and two respectively.



Even when no signal is routed, the outputs send a valid ADAT signal. This can be used to synchronize other devices.

3.17. Network Connection

On the rear of the M-1620 Pro, two RJ45 connectors labeled **NETWORK PRI** and **SEC** provide ethernet connectivity. The supported link speed is **1 Gb/s** for AVB.








A yellow LED (left, **LINK**) signals a successful link. A green LED (right, **ACT**) signals network traffic (blinking).

Both straight and crossover cables can be used (*Auto MDI-X*). Cable lengths of up to 100m are supported when using Cat 5e or higher classification.

The network ports are used to send and receive:


- up to **eight AVB audio streams** when connected to AVB switches and endpoints,
- **one CRF clock stream**,
- remote status/control with **ATDECC**, and
- remote status/control with **HTTP** over IP routed networks.

The current link state is also shown on the display of the M-1620 Pro. Two network port icons in the menu reveal the following states:

| | Icon | Description |
|---|---|---|
|  |  | No link - cable not connected |
| |  | Negotiating link with other endpoint |
| |  | Link with speed of 100 MBit/s (not supported for audio streams) |
| |  | Successful link with speed of 1 GBit/s |


3.18. Word Clock

Word clock can be sent and received via 75 Ω coaxial cabling at the corresponding BNC connectors. The cable length should not exceed 100 m (330 ft).



The input is terminated with 75 Ω internally. To pass on the word clock to other devices, use the word clock **output**. Do not connect a T-adaptor to the word clock input.

The state of an incoming word clock signal can be accessed in the **CLOCK** section.




Possible States:

- A **green indicator** shows that the signal is currently in sync with the chosen clock master.
- An **orange indicator** means that a word clock is received but is not in sync.
- A **red indicator** means that word clock is chosen as master, but a signal is not present or has a different sample rate than the chosen one.

3.19. USB 2.0 Type B Jack

The USB jack at the rear of the M-1620 Pro provides an alternative connection method for web remote control when a network connection is not available.



When connecting the M-1620 Pro with a standard ("printer") USB 2.0 cable to a computer with a current Microsoft Windows™ or Apple macOS™ operating system, a virtual USB network adapter will be automatically installed using generic drivers that are included with the operating system. The device can then be remotely controlled by opening the URL <http://172.20.0.1> in a browser.




The USB port cannot be used to stream audio signals.



Only **one** of the following products can be connected to the host computer via USB at a time: RME M-32 AD Pro (II, II-D), M-32 DA Pro (II, II-D), 12Mic, 12Mic-D, AVB Tool, M-1610 Pro, M-1620 Pro.

3.20. Mounting the Rack Adapter Brackets

When the device should be mounted in a 19" rack, the rack adapter brackets must be mounted first.



Mount each bracket with two screws using a Philips PH-1 screwdriver.



Do not use screws other than the ones included. Using longer screws can damage the device internally!



Never insert the screws without the rack adapter bracket. This could damage the device!

4. Accessories

RME offers several optional components for the M-1620 Pro:

| Part Number | Description |
|--------------------------------|---|
| <i>External Power Supply</i> | |
| NT-RME-11 | External power supply with locking connector, 12 V DC, 3 A, 40 W |
| <i>Analog breakout cables</i> | |
| AI25-8XPro3 | Analog breakout cable 25-pin D-sub to 8 x XLR female, 3 m (9.9 ft) |
| AI25-8XPro5 | Analog breakout cable 25-pin D-sub to 8 x XLR female, 5 m (16.4 ft) |
| AI25-8XPro10 | Analog breakout cable 25-pin D-sub to 8 x XLR female, 10 m (33 ft) |
| A025-8XPro3 | Analog breakout cable 25-pin D-sub to 8 x XLR male, 3 m (9.9 ft) |
| A025-8XPro5 | Analog breakout cable 25-pin D-sub to 8 x XLR male, 5 m (16.4 ft) |
| A025-8XPro10 | Analog breakout cable 25-pin D-sub to 8 x XLR male, 10 m (33 ft) |
| <i>19" XLR breakout panels</i> | |
| DT0X-16 I | 16x XLR Input to 2x D-sub |
| DT0X-16 O | 2x D-sub to 16x XLR Output |
| <i>SFP Modules</i> | |
| MADI-SFP-MM | MADI optical multi-mode module, 2 km, LC, with SC adapter |
| MADI-SFP-SM | MADI optical single-mode module, 20 km, LC, with SC adapter |
| <i>MADI Optical cables</i> | |
| MADI1S | MADI Optical Cable, Simplex, SC-SC, 1m (3.3 ft) |
| MADI3D | MADI Optical Cable, Duplex, SC-SC, 3m (9.9 ft) |
| MADI6D | MADI Optical Cable, Duplex, SC-SC, 6m (19.8 ft) |
| MADI10D | MADI Optical Cable, Duplex, SC-SC, 10m (32.8 ft) |
| MADI20D | MADI Optical Cable, Duplex, SC-SC, 20m (65.6 ft) |
| MADI50D | MADI Optical Cable, Duplex, SC-SC, 50m (164 ft) |

Third party accessories available from independent global retailers:

Optional power cords with locking mechanism

| Manufacturer | Part Number | Description |
|--------------|-------------|----------------------------|
| Schurter | 6051.2032 | CN CORDSET 10A 2.0M V-LOCK |
| Schurter | 6051.2003 | EU CORDSET 10A 2.0M V-LOCK |
| Schurter | 6051.2031 | JP CORDSET 10A 2.0M V-LOCK |
| Schurter | 6051.2008 | UK CORDSET 10A 2.0M V-LOCK |
| Schurter | 6051.2001 | US CORDSET 10A 2.0M V-LOCK |

5. MILAN® AVB Connectivity

This device implements MILAN®, which is an interoperability standard for time aware ethernet networks based on AVB. In comparison to legacy ethernet, an AVB network offers deterministic audio streaming with fixed, precise latency alongside other traffic - out of the box. A separation of audio or control traffic from any other type of network traffic is not necessary.

Network Control

The M-1620 Pro is a MILAN-compliant endpoint device that can be configured with the IEEE Standard for Device Discovery, Connection Management, and Control Protocol for IEEE 1722™ Based Devices, in short: **ATDECC**.



This device does not provide an ATDECC controller for other devices on a network. To establish an AVB connection between devices, a separate controller is required.

There are several ATDECC controllers available for download from different manufacturers that support the commands required to

- identify the device,
- adjust its sampling rate and clock source, and
- create connections to or from it.

Some additional configuration options of the M-1620 Pro may not be implemented in generic ATDECC controllers. These can be inspected and controlled on the device itself, with the web remote, or using a JSON API.

A recommended controller is the **MILAN Manager**, which can be downloaded from the following link:

- <https://www.milanmanager.com>

Audio Streaming

The M-1620 Pro has nine outgoing and nine incoming stream ports. Eight ports can be configured to contain 1-8, 12 (at up to 96 kHz) or 16 (at up to 48 kHz) audio channels in AAF or AM824 format. The ninth port supports only the clock reference format (CRF) and is exclusively used for clocking, not for audio streaming.

In order to establish a connection (*stream*) between two AVB devices, the following conditions must be fulfilled:

1. There must be a *physical* connection between the devices.
2. All switches between the devices must be certified AVB switches (or compatible).
3. An *ATDECC Controller* is required to find the devices and to connect them.
4. Talker and listener must support the stream format and channel count.




A stream between two AVB devices is deterministic, has a fixed latency, and reserved bandwidth.

5.1. Identifying a Device Remotely

When several M-1620 Pros are connected to the same network, each device has its own remote control. To quickly reveal which device is currently being controlled, the web remote and any ATDECC

controller can send an **Identify** command. This shows a confirmation screen on the display of the corresponding device.

To start device identification with the web remote:

1. Open the M-1620 Pro web remote in a browser (see [Section 8.5.1, "Finding the Device on a Network"](#))
2. Press the **identify**  icon.



Depending on the controller, the animation may persist infinitely or stop after a short period of time.

5.2. Changing the Device Name

A custom name can be assigned to the device. It is used to identify the AVB entity with ATDECC controllers. It also allows the access to the web remote without using the IP address on Apple macOS™ computers.





The device name is stored to and recalled from **presets**. Loading a preset can therefore change the device name. The device name is not affected by firmware updates.

Changing the device name is only possible via web remote or ATDECC controller.

To change the device name:

1. Connect the device by USB or network cable and open the [Section 8.5.1, "Finding the Device on a Network"](#).
2. The device name is shown beneath the RME logo. Click the current name to show a text field.



3. Type a new name into the text field and press **Enter** or click . The name is immediately applied.



If the device name is used to access the remote control (within the URL, ie. <http://devicename.local/>), the link to the device changes along with the change of the device name and must be re-entered. The previous URL will not work.

5.3. AVB Stream Size and Format

In an AVB network, a **stream** describes a connection between a **talker** and one or more **listeners**. It consists of a fixed number of audio channels at a fixed sample rate. The *stream port* of the talker and the listener must be configured to have the same amount of channels and stream format, with one exception: streams with less than eight channels can be connected to a listener stream ports of eight channels. Once a stream is connected, each AVB switch along its way ensures that the audio channels can pass in time.

For audio transport, AVB audio endpoints support the AM824 Stream Format or the more efficient AVTP Audio Format (AAF). Additionally, they may support the Clock Reference Format (CRF), which contains only clock information, but no audio.

The M-1620 Pro supports a total of **eight incoming audio streams** and **eight outgoing audio streams** with up to 16 channels in each, and an additional clock reference format stream for clocking that does not contain any audio channels.

5.4. AVB Network Latency

All devices in an AVB network share the same time. This allows the sending device (*talker*) to specify the precise point of time when its audio samples should be played out at any receiver (*listener*). This is achieved by adding an **offset** to the current time and transmitting the resulting timestamps along with the audio payload. The timestamp is called "presentation time" and has nanosecond precision. For comparison, a single sample at 48 kHz has a duration of over 20800 ns.

The receiver compares the incoming presentation time of each frame to the current time and buffers the sample until the presentation time is has come.

The offset (*maximum transit time*) is specified by the AVB standard as 2 ms for class A traffic, which is enough time for the signal to pass through a very large network under full load with over ten Gigabit switches ('hops') along the way. By default, certified AVB products will use this offset, even though it results in a significantly higher latency than necessary in most cases. In smaller Gigabit networks, the offset can be adjusted to lower values, such as 0.3 ms, 0.6 ms or 1 ms. It can be adjusted for each stream individually.

If the digital outputs of listener devices should to be phase aligned to the talker, is necessary to choose an offset that is a multiple of a sample length (which is *1 divided by sampling rate*). Using the web interface, the offset can be conveniently set in **samples** for each stream to ensure phase alignment between talker and listeners across the network.

Table 1. Recommended presentation time offset (estimated maximum transfer time) depending on network size, in samples, for Gigabit networks

| Rate (Hz) | 1 switch (~0.3 ms) | ≤3 switches (~0.6 ms) | ≤6 switches (~1 ms) | Default (~2 ms) |
|--------------|-----------------------|--------------------------|------------------------|--------------------|
| 44100 | 14 | 27 | 44 | 88 |
| 88200 (x2) | 28 | 54 | 88 | 176 |
| 176400 (x4) | 56 | 108 | 176 | 352 |
| 48000 | 15 | 30 | 48 | 96 |
| 96000 (x2) | 30 | 60 | 96 | 192 |
| 192000 (x4) | 60 | 120 | 192 | 384 |

In the event that the chosen offset is too low, the audio stream may experience drop-outs or distortion. However, the maximum transit time to a specific listener is known, and an ATDECC controller can show a warning if the intended presentation time is earlier than the calculated maximum transit time for that stream.



As a rule of thumb, 0.125 ms should be added for each device (talker, switch, listener) along the way.



In AVB networks, the latency is always specified by the talker and guaranteed by the switches along the way and the listener. This behavior is *plug and play* and does not require any user interaction or monitoring for the entire duration of the stream.

6. Quick Start (MADI)

Follow this procedure to get running quickly!


1. Load **Preset 16** (Factory settings) from the **STATE** section




2. In the **CLOCK** section, choose a sample rate and verify that the device is set to internal clock reference or that the chosen clock source is in sync.




3. After connecting an analog signal, adjust its reference level as needed in the **INPUT** section




4. Open the tab of the preferred digital output in the **OUTPUT** section and choose "Analog 1-16" as source.



5. Set the preferred reference level in the analog configuration tab of the **OUTPUT** section



6. Choose a digital input source for the analog outputs in the **OUTPUT** section



☑ done!

Further steps to enhance your start:

State

- [Section 8.1.1, “Notification of Single Power Failure”](#)
- [Section 8.2.2, “Loading Presets”](#)
- [Section 8.3.1, “Locking the Device”](#)
- [Section 8.4.1, “Dark Mode”](#)
- [Section 8.5.3, “Web Remote”](#)
- [Section 2.2, “Firmware Update”](#)

Input

- [Section 9.1.1, “Adjusting the Input Line Level”](#)
- [Section 9.2.2, “Connecting Two Identical MADI Signals for Redundancy”](#)
- [Section 9.3.1, “Change AVB Input Stream Size”](#)

Output

- [Section 10.2.2, “Mute Analog Outputs”](#)
- [Section 10.1, “Routing Signals to the Outputs”](#)
- [Section 10.4.1, “Change AVB Output Stream Size and Format”](#)
- [Section 10.3.1, “Setting the Output Channel Format and Frame Pattern”](#)

7. Warranty and Support

7.1. Warranty

Each individual M-1620 Pro undergoes comprehensive quality control and a complete test before shipping. The usage of high grade components should guarantee a long and trouble-free operation of the unit.

If you suspect that your product is faulty, please contact your local retailer. Do not disassemble the device by yourself as it may get damaged. It has been sealed with tamper-evident material, and your warranty is void if those seals have been damaged.

The distributor grants a limited manufacturer warranty of 6 months from the day of invoice showing the date of sale. The length of the warranty period is different depending where the product was purchased. Please contact your local distributor for extended warranty information and service. Note that each country may have regional specific warranty implications.

In any case warranty does not cover damage caused by improper installation or handling - replacement or repair in such cases can only be carried out at the owner's expense.

No warranty service is provided when the product is not returned to the local distributor in the region where the product had been originally shipped.

The distributor does not accept claims for damages of any kind, especially consequential damage. Liability is limited to the value of the M-1620 Pro. The general terms of business drawn up by the distributor apply at all times.

7.2. Support

Please ensure that you are using the latest firmware before contacting support.

In many cases, the user forum at <https://forum.rme-audio.de> provides help with a simple search for relevant keywords.

If the problem cannot be solved by any of the aforementioned methods, please have your serial number at hand and contact your local dealer or distributor. A complete list of distributors can be found on the RME website.

7.3. Support Contacts

The following global service centers can provide support assistance:

| | | |
|-----------------------|-----------|--|
| Europe | Germany | Audio AG support@rme-audio.com |
| | U.K. | Synthax Audio U.K. info@synthax.co.uk |
| Asia/Australia | Hong Kong | RME Trading Ltd. support@rme-trading.hk |
| Americas | U.S.A. | Synthax Inc. support@synthax.com |
| Global | | support@rme-audio.com |

8. STATE Section

The **STATE** section contains states and settings that are unrelated to audio I/O and clock. It can be used to configure power supply warnings, presets, dark mode, level meters, and remote control.

A **warning** (red) is shown when PSU redundancy is activated but only one power supply is active. A **notification** (orange) is shown when a preset is modified, no IP address was assigned to the web remote or any dark mode is active.


8.1. Power State



The power tab in the **STATE** section informs the user which of the two power inlets receive power. Its icon is a realtime representation of the current power state, with an inactive power supply shown in grey. The AC input corresponds to the left icon, the DC input to the right icon.

Representation of the state of power supplies on the device


1. Open the **power** tab in the **STATE** section



2. The state of each power input is shown as *active* if it receives power.

Representation of the state of power supplies on the web remote

1. Connect the device by USB or network cable and open the [Section 8.5.1, “Finding the Device on a Network”](#).



2. A click on the Power icon reveals the current state of the power supplies.

8.1.1. Notification of Single Power Failure

A warning can be displayed when one of two connected power sources fails.


On the display, a warning is signaled as an icon with a red bar:



Power loss at secondary PSU

To activate the warning on the device:

1. Open the **power** tab in the **STATE** section.



2. Toggle the switch **Redundancy** to **On**.

To activate the warning on the web remote:

1. In the **STATE** section, activate the toggle next to **Power Loss Warning**.



The warning signals only the current state. It does not keep a record of past power failures.

8.2. Presets

Any change in the device configuration is persistent. After a power loss, the device will revert back to its last state. Additionally, the M-1620 Pro can save fifteen states in presets numbered 1-15. After a preset is loaded, any change in the configuration will result in an *unsaved changes* state.



Representation of an unsaved preset on the device.



The internal preset storage is not affected when the device firmware is updated to a newer firmware version. Moreover, recalling the factory default preset does not delete any other saved preset.

Settings that are not saved in a Preset

The following settings are **not saved** in a preset:


- Auto-lock
- Lock code
- Remote control
- Static IP/DHCP configuration
- MIDI Remote Control ID

8.2.1. Saving Presets

Up to 15 presets can be saved in the internal storage of the M-1620 Pro.

To save a preset on the device:


1. Open the **preset** tab in the **STATE** section. The cursor will highlight a preset number.



2. Push and rotate the encoder to choose a preset number.
3. Push **Save** to save the preset.

To save a preset using the web remote:

1. Open the web remote and locate the **preset** tab.



- 1 Status Indicator and tab
- 2 Current preset and state
- 3 Selected preset
- 4 Save preset

2. Click on a preset name in the left column (3) to select a preset.
3. Press the **Save** button (4).

8.2.2. Loading Presets

Up to 15 custom presets can be loaded from the internal storage of the M-1620 Pro.



Loading a preset cannot be undone. Ensure that any important configuration has been saved to another preset before proceeding.



The device name is part of the preset. When a preset is loaded, the device name is changed to the value stored in the preset.

To load a preset on the device:

1. Open the **preset** tab in the **STATE** section (see: [Section 2.3, "Use of the Display and Encoder"](#)).



2. Move the cursor to the current preset number and push the encoder.
3. Rotate the encoder to choose a preset, and confirm by pushing the encoder.
4. Select **Load** to load the preset.

To load a preset using the web remote:

1. Locate the **preset** tab
2. Use the drop-down menu **3** to select a preset.
3. Press the **Load** Button **4**.

8.2.3. Loading Factory Default Settings

The factory default settings are saved internally as **Factory Preset** and cannot be overwritten.

To load the factory defaults, **load** the 16th preset labelled **Factory Preset**.



Loading the factory defaults does not delete any saved presets. It also does not affect the **lock** settings in the **STATE** section.

8.3. Device Lock

The M-1620 Pro can be secured against both accidental and intentional changes to its configuration. **Locking** the device, with or without code, protects against changes on the device itself. When locked, the display shows a lock symbol.




The device lock does not protect against changes via remote control. The lock configuration is not stored within a **preset**.



A four to six digit code can be configured on the device. If this code is lost or forgotten, it is not possible for the user to unlock the device. Contact [your support](#) for assistance.

8.3.1. Locking the Device



In order to lock the device, proceed with the following steps:

1. Open the **lock** tab in the **STATE** section (see [Section 2.3, "Use of the Display and Encoder"](#)).

2. (optional) **Set Code**: enter a four to six digit code with the encoder.
3. (optional) Activate the **Auto Lock** toggle to lock after one minute.
4. (optional) Select **Lock Device Now** to lock immediately.



Remember or write down the code shown in **SET CODE**. It is not possible to unlock the device without this code. A unique secondary code (PUK) can be obtained from RME Support upon request with a proof of purchase and device serial number.

To delete the code, move the cursor on the code and push the encoder. "No code" will be displayed.

The device can only be locked and unlocked at the front panel. These controls are not accessible remotely.


8.3.2. Unlocking the Device

To unlock the device temporarily:

1. Push and hold the encoder button for four seconds.
2. (if a code was set) Enter the code using the encoder and choose "Done".

The device will lock again after a timeout of one minute.

To unlock the device permanently:

1. Proceed as above, then
2. Open the **lock** tab in the **STATE** section
3. Deactivate the lock by toggling the switch to:  **OFF**
4. (optional) Move the encoder onto the lock code (if any), and push the encoder to delete it.

The device can only be locked and unlocked at the front panel. These controls are not accessible remotely.

8.4. Front Panel Illumination

The M-1620 Pro features a unique concept for its front panel illumination, which consists of:

- A ring illumination around the **standby switch** that shows the overall state of the device,
- 36 LED level meters for analog input and output channels, and
- a display with standby screen that shows categorized warnings.

All elements have been designed to give the user thorough status feedback even from a distance. The LED level meters can be configured to hold maximum levels for 5 s or infinitely. Each of the three sections can be individually switched off (**dark mode**). The M-1620 Pro features a unique concept for its front panel illumination, which consists of:

- A ring illumination around the **standby switch** that shows the overall state of the device,
- 32 6-segment level meters, and
- a display with standby screen that shows categorized warnings.

All elements have been designed to give the user thorough status feedback even from a distance. Each of the three sections can be individually switched off (**dark mode**).


Level meter strips

The six-segment level meter strips provide a convenient indication of the current signal level. The



LEDs vary in brightness to represent different levels, making intermediate values easy to read. The brightest LED corresponds to the value indicated beside it. This technology enables the M-1620 Pro to display a range from –70 dBFS up to clipping using only six LEDs.

8.4.1. Dark Mode

Each of the three front panel illumination sections can be switched off if they are not required.




To turn off illumination on the device:

1. Open the **visual feedback** tab in the **STATE** section.
2. Change any of the following:
 - a. **Power** to  **Off** to turn off the standby switch ring illumination.
 - b. **Level LEDs** to **Off** or **Dim** to turn off or dim level meter LEDs.
 - c. **Display** to  **Off** to turn off the display.



When any item is turned off, a notification (orange) is shown in the **STATE** section.

To turn panel illumination back on:


1. Open the same menu and set the corresponding switches to  to **On**.



To turn the front panel lighting on temporarily, just rotate or push the encoder. The panel will turn back off after five seconds.

To turn off illumination on the web remote:

1. Connect to the device remotely (see: [Section 8.5.1, "Finding the Device on a Network"](#)).



- 1 Status Indicator
- 2 State of Visual Feedback
- 3 Front Panel Dark Mode
- 4 Global Metering Options
- 5 Peak/Over Hold Reset


2. Use the corresponding toggle switches on the web remote to switch off device lighting.

8.4.2. Changing the Meters to Peak or RMS Mode

Depending on the application, instantaneous **peak level metering** or a slower, averaged **RMS metering** may be preferred.

To change the metering mode on the device:

1. Open the **visual feedback** tab in the **STATE** section.



2. Push the encoder on the current "Metering:" value to activate selection.
3. Change the value to "Peak" or "RMS".

To change the metering mode on the web remote:

1. Connect to the device remotely (see: [Section 8.5.1, "Finding the Device on a Network"](#)).

2. Locate the **visual feedback** tab in the **STATE** section.
3. Push the **Peak** or **RMS** button in the **global metering** settings.




This is a global setting which affects both the front panel level meters and the remote control interface.

8.4.3. Persistent Clipping Notifications and Peak Hold

The maximum level of signals can be saved and shown on the front panel and web remote. Clipping is detected when three consecutive samples reach digital full scale (0 dBFS). The duration of how long the maximum level or clipping is shown can be manually changed to either five seconds or until they are manually reset.




This is a global setting which affects both the remote control and the device.



On the device, an over notification is signaled as a fast flashing (red) of the 0 dB LED.

To switch over notifications on or off:

1. Open the **visual feedback** tab in the **STATE** section



2. Change **OVR Hold** to either:
 - **5s** to notify for five seconds
 - **On** to notify until manually reset
 - **Off** to deactivate over notifications.

To reset infinite full scale notifications:

1. Open the **visual feedback** tab in the **STATE** section.
2. Activate **Reset**.

The remote shows an over notification above the level meter, both in miniature port level meters and the larger level meters when a port is open.

To switch persistent over notifications on or off:

1. Locate the [Visual Settings Tab](#).
2. Change **Peak + OVR Hold** to either
 - **5s** to notify for five seconds
 - **On** to notify until manually reset
 - **Off** to deactivate over notifications

To reset over notifications:


1. Within the [Visual Settings Tab](#), use the reset button: .

8.4.4. Metering of Digital Signals


The incoming and outgoing digital signals can be visually inspected to ensure that signals are properly received and routed. All level meters adhere to IEC 60268-18 scaling and feature RMS levels with a separate peak indicator. Peak and over hold times can be configured in [Section 8.4.3, "Persistent Clipping Notifications and Peak Hold"](#).

To show the digital level meters on the device display:

1. Open the input section (see: [Section 2.3, "Use of the Display and Encoder"](#)).



On the web remote, each input and output port has integrated level meters.



When opening the ports, larger levelmeters are shown with precise levels for Peak and RMS values.

8.5. Remote Control Overview

The M-1620 Pro can be remote controlled. Remote control is activated by default and is not affected by preset changes or device lock.

The network controls over HTTP and ATDECC operate simultaneously. Two or more controller instances are synchronized. Both network and MIDI control can be used at the same time.



The remote control protocols are not protected against malicious use. When activated, the remote control server allows anyone on the network to make changes to the configuration of the device. To limit access, secure the network that the device is connected to.

8.5.1. Finding the Device on a Network


The M-1620 Pro has three integrated network adapters (USB 2.0 and dual ethernet).

The adapters can be used, individually or simultaneously, to control the device with HTTP ("web remote"). The web remote control works on any IP-based network, including wireless networks.

The ethernet connection additionally supports ATDECC 1722.1 remote protocol, which requires a physical connection (cables), but does not require AVB switches. Wireless routers are not supported for ATDECC.

To enable web remote functionality over HTTP:

1. Open the **remote** tab in the **STATE** section.



2. Ensure that the **HTTP Remote** setting is switched to **ON**.

USB

When the device is connected with a USB 2.0 cable to a Apple macOS™ or Microsoft Windows™ computer, a network device is automatically installed in the background that assigns the M-1620 Pro the following IP address:

<http://172.20.0.1>



Only **one** of the following products can be connected to the host computer via USB at a time: RME M-32 AD Pro (II, II-D), M-32 DA Pro (II, II-D), 12Mic, 12Mic-D, AVB Tool, M-1610 Pro, M-1620 Pro (D).

Ethernet


After connecting the primary or secondary port of the M-1620 Pro to a network, an IP address will be automatically assigned by a DHCP server that is present on that network. If there is no DHCP server on the network, the device assigns itself a *link local* address (in the 169.254.0.0/16 subnet) on the primary port.



Automatically assigned link-local addresses are only supported on the Primary network port.

To find out the current IP address:

1. Open the **network** tab in the **STATE** section.



2. The current IP addresses of both networks are displayed.
3. Enter the IP address of the corresponding network in the address bar of the browser.

Connecting to the Remote Interface without IP address

Instead of using the IP address, the **device name** can be entered in the browser window, followed by **.local/**.

The current device name is shown on the standby screen between the 'Clock' and 'Output' sections. It may be abbreviated if it does not fit in the corresponding space.

By default, the name is m1620-pro, and the corresponding URL is therefore:

<http://m1620-pro.local/>



The length of the custom name should not exceed 63 characters. Spaces, underscores and other special characters in the device name should be written as hyphens ("-") when entering the URL.



on some operating systems or browsers, a trailing dot "." may be required after the 'local' domain: <http://m1620-pro.local/>



The device name is stored in a preset. Loading a preset can therefore change the device name and require a different address.

8.5.2. Assigning a Static IP Address


A static IP address can be assigned for each network port. Other devices with IP addresses in the same subnet can then reach the M-1620 Pro using a fixed IP address.



The static IP address configuration is persistent and does not get deleted when a preset (or factory preset) is loaded.

To manually assign an IP address:

1. Open the **Network** tab in the **STATE** section of the main menu.



2. Toggle either **PRI IP** or **SEC IP** to **Static** by pressing the encoder.
3. Navigate to the IP address and begin editing by pressing the encoder. Entering one decimal octet at a time, confirming each with an encoder press.
4. Navigate to the subnet mask and press the encoder to edit it. This is again performed and confirmed with the encoder.
5. Changes are applied when leaving the tab.

8.5.3. Web Remote


An integrated web server provides an easy-to-use remote control interface for the M-1620 Pro. It requires a network connection from a desktop or tablet computer with a current browser version.

Compatible browsers:

- Chrome 127
- Firefox 127
- Edge 127
- Safari 17.0

or newer with support for WebGL.

Web Remote Overview



- 1 Section 2.2, "Firmware Update"
- 2 Section 5.1, "Identifying a Device Remotely"
- 3 Section 8.1, "Power State"
- 4 Section 8.2, "Presets"
- 5 Section 8.4, "Front Panel Illumination"
- 6 Section 10.1, "Routing Signals to the Outputs"
- 7 Section 11, "CLOCK Section"
- 8 Section 9, "INPUT Section"
- 9 Section 9.1, "Analog Inputs"
- 10 Section 10, "OUTPUT Section"

8.5.4. JSON(OSC) Remote Control

This topic describes a method for remote control modeled loosely after the Sennheiser® Sound Control protocol. Detailed background information on the underlying technology can be found on the Sennheiser® website.

The M-1620 Pro can be remote controlled with HTTP POST requests. Each request carries a data payload that contains a JSON object modeled after the open sound control (OSC) protocol.

For example, if the device is connected to a computer that can run *cURL* in a terminal application (Microsoft Windows™ PowerShell or Apple macOS™ Terminal), the following command will request the entire device schema as a JSON object:

Request:

```
curl --header "Content-Type: application/json" --request POST --data
'{"osc":{"schema":null}}' m1620-pro.local/api/v2/self
```

Response:

```
{
  "osc": {
    "schema": {
      "osc": {
        "version": null,
        "schema": []
      },
      "device": {
        "entity_id": null,
        "entity_model_id": null,
        "entity_capabilities": null,
        "entity_name": null,
        "vendor_name": null, ①
        "model_name": null,
        "firmware_version": null,
        "group_name": null,
        [... continues]
```

① "vendor_name" Object

This schema can then be used to identify the possible parameters, for example the vendor name. Sending an empty value **null** triggers a response with the current value of the requested object.



The first two levels of the schema ({"osc": {"schema": {...}}}) must be omitted. Only the encapsulated objects (**device**, **input**, **output**, **routing** etc.) are used.

To request the "vendor_name" object of the connected device, we run the following command. It is here outlined in more detail.

Request of vendor name:

```
curl \ ①
--header "Content-Type: application/json" \ ②
--request POST \ ③
--data '{"device": {"vendor_name": null }}' \ ④
m1620-pro.local/api/v2/self ⑤
```

- ① cURL command to send an HTTP POST request
- ② header: application/json
- ③ request type "POST"
- ④ JSON object sent to the device, 'null' to get current value
- ⑤ URL or IP of the device on the network with path to API

Executing this command delivers the expected result:

```
{"device":{"vendor_name":"RME Audio"}}
```



The entire web remote application is based on this protocol. It is therefore possible to read the data payloads sent to the device when interacting with the web remote by using the "Network"-tab of the developer tools inside the browser.

All device values must be polled by sending the corresponding JSON objects. It is possible to poll or set several values at once in a single object:

Set reference level to +13 dBu for analog inputs 1-4

```
--data
'{"input":{"analog":{"1":{"reference_level":13},"2":{"reference_level":13},"3":{"reference_level":13},"4":{"reference_level":13}}}}'
```

8.5.5. JSON(OSC) Implementation Chart

The implementation chart is currently not included in this PDF. Please see the chart in the online version of this manual.

<https://docs.rme-audio.com>

8.6. Monitor Fan Speed and Temperature

The M-1620 Pro has three temperature sensors to monitor its temperature and to adjust fan speed in relation to those temperatures.

There are three fan speed profiles:


- Off
- Cool
- Normal

It is recommended to first improve overall ambient temperature and airflow around the unit, especially at its bottom and sides, to minimize fan noise. When using the M-1620 Pro in a hot environment, the **Cool** fan profile can be used to improve air flow. In silent environments, the **Off** profile can be used to only start the fans when the device is overheating.

8.6.1. Adjust Fan Profile


To change the current fan profile on the device:

1. Open the **STATE** section (see: [Section 2.3, "Use of the Display and Encoder"](#))
2. Use the encoder to open the Temperature/Fan tab:



3. Select the preferred fan profile.

To change the current fan profile on the web remote:

1. Open the  menu (see: [Section 8.5.1, "Finding the Device on a Network"](#))
2. Navigate to 'Device Health'

Device Health

Temperatures

Processor: 82 °C Analog Section: 53 °C Env. Temperature: 47 °C

Fan Control

Profile: Off

Current Speed: 0

3. Select the preferred fan profile.

8.7. Anti-Aliasing Filter

Anti-aliasing filters are low-pass filters that attenuate frequencies near the Nyquist frequency (half the sampling rate) to prevent aliasing artifacts during digital conversion. A steeper ("sharp") filter maintains a linear frequency response up to the cutoff frequency but introduces increased ringing artifacts in the impulse response due to its abrupt transition. In contrast, a "slow" filter with a gentler slope may cause slight attenuation of high frequencies (treble), which can be audible at standard sampling rates, but provides a near-perfect impulse response with minimal ringing.

By default, the M-1620 Pro employs a sharp filter with short delay at standard sampling rates (44.1 kHz and 48 kHz) and a slow filter with short delay at higher sampling rates (88.2 kHz, 96 kHz, and above). However, the filter settings can be adjusted globally for both inputs and outputs. This flexibility is beneficial when maintaining a linear frequency response in the ultrasonic range is important for the given application (ie. measurements).

There are four aliasing filters:

- Slow
- Sharp
- Short-Delay Slow (default for $SR \leq 48$ kHz)
- Short-Delay Sharp (default for $SR \geq 88.2$ kHz)


The Short-Delay options are IIR filters that reduce the overall delay of the conversion to a few samples, while the other two filters are FIR filters offer phase-linearity across the entire frequency range.

8.7.1. Changing the Aliasing Filter

The aliasing filter is stored within the current **preset** and is recalled when loading a preset. By default, it is set to **Auto**, which sets an anti-aliasing filter with sharp roll-off for single speed and with slow roll-off for double and quad speed.

To change the aliasing filter on the device:


1. Open the **STATE** section (see: [Section 2.3, "Use of the Display and Encoder"](#))
2. Use the encoder to open the *filter* tab:





3. Select the preferred aliasing filter.

To change the current aliasing filter on the web remote:

1. Click an analog channel group to reveal its channels



2. Click the  icon that appears within the corresponding analog channel group. A modal dialog appears to change the aliasing filter.



3. Select the preferred aliasing filter.



The aliasing filter affects both input and output conversion filters. It is not possible to control them separately.



Changing the filter might cause a brief noise on the analog channels.

8.8. Device Information

The **information** tab is located in the **STATE** section.



It shows the current firmware version and gPTP grandmaster IDs.

The information tab is only available on the device itself.

9. INPUT Section

The input section is used to inspect and configure the audio inputs of the device. A warning is displayed when a digital input is not present but selected as clock master, or routed to an output and is either not present or not in sync to the clock master. Related input settings, such as AVB stream size or MADI auto input, can be configured here.

9.1. Analog Inputs

The line level inputs of the M-1620 Pro accept levels of up to +24 dBu. Each individual channel has its own line level setting of +13/+19/+24 dBu which can also be adjusted remotely. Additionally, the AD converters can be globally set to standby (mute).

At single speed sample rates, the converters are configured with short delay 'sharp' IIR filters with extremely low latencies (5 samples) and flat frequency response over the entire audible range. At higher sample rates, a short delay 'slow' filter is used to additionally optimize the impulse response. The latency increases to six samples at quad speed (176.4 kHz, 192 kHz).

In its default state, no routing exists between the analog inputs and the digital outputs. The analog signals can be routed to two MADI ports and eight AVB streams at the same time.


9.1.1. Adjusting the Input Line Level

To adjust the input line level on the device:

1. Open the **Analog Input** tab in the **INPUT** section



2. Initially, the cursor will highlight all input channels. To accept this, rotate the encoder to move the cursor to the current reference level
3. Alternatively, pressing the encoder on the channel strip allows the selection of an individual channel



- | | |
|----------|--------------------------|
| 1 | Cursor (current channel) |
| 2 | Input Reference Level |

4. Push the encoder on the current line level, then Rotate the encoder to change the setting and confirm by pushing the encoder again.

To adjust the input line level on the web remote:


1. Select one or more analog input channels by clicking the corresponding channel strips. The channel strips turn blue.
2. (*alternative*) Click and drag left or right to select consecutive channels.
3. Press one of the buttons for **+13 dBu**, **+19 dBu** or **+24 dBu** below the selection. The selected value is shown within the level meter.

9.2. MADI Inputs

The M-1620 Pro accepts up to two MADI signals, one electrical (BNC input) and one optical via optional SFP module (LC input).

To connect a MADI signal:

1. Ensure that you have set the correct sample rate and clock source in the **CLOCK** section.
2. Connect the cable to the corresponding input.
3. Open a **MADI** tab in the input section to see the current LOCK state, SYNC state, and input signal levels.



9.2.1. MADI at High Sample Rates

The MADI standard (AES10) allows transport of audio at sample rates beyond 48 kHz by reducing the number of available channels.

Double speed (88.2 kHz, 96 kHz)

Double speed audio signals can be transmitted and received in two different ways. Manufacturers can implement one or both modes, usually referred to as "96k frame" and "S/MUX 2" or "legacy" mode. It is important to use the same mode on both sender and receiver side because S/MUX 2 and legacy mode are not compatible. Both modes transport the audio signal transparently.

96k frame

The so-called "96k frame pattern" (AES10) can be detected at the receiver side automatically. In this mode, the frame numbers and corresponding user bits equal the number of channels submitted. The "56 Ch." setting corresponds to 28 audio channels at 88.2 kHz and 96 kHz sample rates. The "64 Ch." setting corresponds to 32 audio channels at 88.2 kHz and 96 kHz sample rates.

S/MUX 2

Sample multiplexing (or S/MUX 2) describes a method to distribute two consecutive samples onto neighboring channels. The MADI signal remains exactly the same as in single speed with 56 or 64 channels including its user-bits. The receiver decodes the audio signal by passing the samples of channel 1+2 as two consecutive samples for channel 1, samples of channel 3+4 as two consecutive samples for channel 2, and so forth. The amount of channels corresponds to the same as the 96k frame. This format cannot be automatically detected at the receiver side.

Quad Speed (176.4 kHz, 196 kHz)

Quad speed MADI does not have a standardized frame format. Therefore S/MUX 4 is used. The encoding works the same way as S/MUX 2, except that four consecutive channels are used to transport one audio channel. This reduces the available number of channels to 14 ("56 Ch." setting) or 16 ("64 Ch." setting).



When using MADI, the sample rate of the incoming MADI signal and the expected frame format of the outgoing MADI signal must be set in the device.

9.2.2. Connecting Two Identical MADI Signals for Redundancy

The coaxial MADI input can be configured to automatically switch to an existing MADI optical signal in case the coaxial signal fails. While existing routing and clock settings from the coaxial MADI input are kept, the port's name is changed to **MADI Auto Input** and its icon changes to reflect the feature. The failover is seamless if the active input loses lock abruptly (e.g. one of the cables is unplugged).




The user is notified of the lost signal with a warning and redundancy can be re-established.



For a seamless failover, the two MADI signals must be identical. However, only the SYNC and LOCK states are evaluated to confirm the current input state. It is therefore possible to send two different signals to the M-1620 Pro as long as they are in sync.


To create MADI redundancy:


1. Switch on "enable MADI redundancy" in the **coaxial** tab of the **INPUT** section. The port will be renamed to MADI Auto Input.



2. Create a routing from MADI Auto Input to any output.
3. If the device should also slave to MADI Auto Input, choose it as clock master in the **CLOCK** section.
4. Connect both MADI signals with identical audio.

To create MADI redundancy using the web remote:

1. Open the MADI Coaxial input port in the routing view.
2. Click the  icon that appears within the port.
3. Toggle the switch "Auto Input" to **ON**.



9.3. AVB Input Streams

The AVB streams *received* by the M-1620 Pro are referred to as "input streams". For these streams, the device acts as an **AVB Listener**.

To establish a connection between a talker and a listener, an **ATDECC Controller** is required. The M-1620 Pro does not include an ATDECC Controller.

AVB input streams are monitored as follows:

| Description | Indicator | Possible solution |
|---------------------|------------|--|
| Disabled | grey | Create connection with ATDECC controller |
| Streaming/Receiving | green | |
| No Data | red | Verify proper talker configuration |
| SR Mismatch | red | Verify that the sample rates of talker and listener are identical |
| Waiting | yellow ... | Waiting for talker to be ready |
| Talker Fail | red | Verify proper talker configuration |
| No Bandwidth | red | Use faster network speed (1 GBit/s instead of 100 MBit/s) |
| Domain Boundary | red | Reconnect all devices and reboot switch, ensure only AVB switches are used |
| Internal Error | red | Reboot device |

9.3.1. Change AVB Input Stream Size


Each of the eight AVB streams can have a size of 1-8, 12 or 16 channels in AM824 and AAF stream formats.

To change the amount of channels and format of incoming AVB streams on the device:

1. Open the **AVB** tab in the **INPUT** section.




- Move the cursor to highlight the corresponding AVB stream **size** and press the encoder.



- Rotate the encoder to configure a new stream size and format, then confirm by pressing the encoder again.

To change the amount of channels of the incoming AVB streams using the web remote:

- Connect the device by USB or network cable and open the [Section 8.5.1, "Finding the Device on a Network"](#).
- Open an AVB port in the routing area and use the up and down arrows **1** to adjust the stream size.
- Use the stream format dropdown **2** to select the format to be used.



- Click **OK** **3**.



Changing a stream size briefly interrupts all incoming AVB streams.



Incoming streams can contain less than the specified amount of channels.

9.4. ADAT Inputs

There are [four ADAT® Lightpipe S/PDIF connectors](#) that are individually monitored for proper synchronization. If several ports are used at the same time, it must be ensured that they are synchronized - for example by connecting Word Clock or ADAT signals from the M-1620 Pro to the devices and synchronizing them to the incoming digital signal.

To route a signal from the ADAT input to an output of the device, visit the corresponding output section and [create a routing](#) from there.

The channel count depends on the device sampling rate (four channels at double speed, two channels at quad speed). Changing the sampling rate to double or quad speed temporarily hides the channels that cannot be received for each output port, but restores previous routings once the sampling rate is reduced in the clock settings.



At 44.1 and 48 kHz, a maximum of eight channels can be received per port. This amount is reduced to four channels at 88.2 and 96 kHz (double speed), and to two channels at 176.4 and 192 kHz (quad speed) respectively.

10. OUTPUT Section

The output section represents the internal routing matrix and state of the outputs. Routing is performed by selecting an output and assigning any input to it. When a routing is active, its input is automatically monitored for lock and sync in the input section. For AVB stream outputs, their states are additionally monitored in the output section.

Example:

In the **OUTPUT** section, **MADI Optical 1-12** is chosen as source for **AVB Stream 2**.

The M-1620 Pro is clock master, but the incoming MADI signal is not correctly synchronized. This causes a warning in the **INPUT** section. If **MADI Optical** is not routed to any output, an invalid or missing signal does not cause a warning.




Use the web remote to find out quickly which outputs are receiving a specific input signal. The web remote provides a thorough representation of all active routing connections at a glance.

Device Output Section

The device allows full inspection and configuration of outgoing signals including routing with the use of the encoder.

Web Remote Output Section

The web remote integrates the output ports with a visual routing interface. Output ports are shown as icons along the bottom of the screen, with visualized routings that point to the corresponding inputs. Each port can be opened to reveal its output levels, settings, and detailed routing. AVB output ports reveal their current streaming state at a glance.



10.1. Routing Signals to the Outputs

Each output channel of the M-1620 Pro can receive any input signal. The factory default preset does not contain any routing.




A routing immediately activates input monitoring for a corresponding digital input and raises a warning in the input state if the source signal is not available or out of sync.

The following example shows the procedure to route to MADI Coaxial output channels. Other outputs follow the same procedure.

To create a routing to a MADI output on the device:

1. Open the **OUTPUT** section.



2. Rotate the encoder to highlight the coaxial or optical MADI icon.
"Route Signals to MADI Coaxial/Optical Output" text will be shown on the display.
3. Press the encoder to open the routing. The cursor will highlight the first available channel block.
4. Either rotate the encoder to select the next available channel block or press it to start assigning the source signal.
5. Again, rotate the encoder to select the source for the selected output.
Choosing "not routed" deletes an existing routing, and "cancel" aborts the routing and keeps the previous routing.

To create a routing to a MADI output on the web remote:

1. Enter the Routing mode by pressing the corresponding icon in the title bar.
2. Click the MADI coaxial or MADI optical output port.
3. Select individual or consecutive channels by clicking or dragging. The channels are highlighted in blue and an arrow handler is revealed.
4. If the input ports are closed, drag the handle onto an input port, it opens automatically.
5. Drag the handle onto the source channel strips to select a range of channels as signal source.

10.2. Analog Outputs

The line level outputs of the M-1620 Pro operate at +13 dBu, +19 dBu, or +24 dBu. Each individual channel has its own line level setting, which can be adjusted remotely. Additionally, channels can be muted globally or individually.

In its default state, no routing exists between the digital inputs and the analog outputs. Each group of four consecutive outputs can receive its signal from any digital input that is connected and synchronized.

At all sample rates, the converters operate with short delay IIR filters. At single speed, a short delay 'sharp' filter is used to ensure linear frequency response. At double and quad speed, a short delay 'slow' filter is used to optimize the transient response of the M-1620 Pro while maintaining linear frequency response in the audible range. The filters can be changed in the State menu.


10.2.1. Adjusting the Output Line Level

To adjust the output line level:

1. Open the **Analog Output Configuration** tab in the **OUTPUT** section.



- Initially, the cursor will highlight all output channels. To accept this, rotate the encoder to move the cursor to the current reference level.
- Alternatively, pressing the encoder on the channel strip allows the selection of an individual channel.



- | | |
|----------|--------------------------|
| 1 | Cursor (current channel) |
| 2 | Output Reference Level |

- Move the cursor to the current **line level** and push it.
- Rotate the encoder to change the setting and confirm by pushing the encoder again.


To adjust the output line level on the web remote:

- Select an analog output channel by clicking the corresponding channel strip. The channel strip turns blue.
- (optional) Click and drag left or right to select multiple channels.
- Press one of the buttons for **+13 dBu**, **+19 dBu** or **+24 dBu** below the selection. The selected value is shown within the level meter.


10.2.2. Mute Analog Outputs

To mute an individual output channel on the device:

- Open the **Analog Output Configuration** tab in the **OUTPUT** section



- Initially, the cursor will highlight all output channels. Press the encoder, then rotate the encoder to move the cursor to the channel that should be muted.



- 1 Cursor (current channel)
- 2 Channel Mute

3. Move the cursor to **Mute Toggle** and push it.

To mute an output channel using the web remote:

1. Select an analog output channel by clicking the corresponding channel strip. The channel strip turns blue.
2. (optional) Click and drag left or right to select multiple channels.
3. Toggle the **Mute** switch. The status is reflected with a red **M** in the corresponding level meters.

10.2.3. Phones Out


The [front TRS connectors](#) can be used for phones or as balanced mono outputs. Each of the four channels can receive a signal from any connected digital or analog source. A button next to each headphone jack gives access to all features of the output.

10.2.4. Adjusting the Headphone Volume

The volume of the unbalanced phone outputs can be adjusted separately or as a stereo pair.

To adjust the headphone volume on the device:

1. Press the **PH 1/2** or **PH 3/4** Button next to the corresponding headphone output.
2. Rotate the encoder to adjust the gain.



To adjust the phones output level:

1. Open the corresponding output channel strip.
2. Use the encoder to adjust the gain in the 'PHONES' channel strip.



Press the **Shift** key while dragging the knob for finer adjustments.



Clicking twice on the encoder knob opens a text field that can be used to input a value using the keyboard.

To separate the left and right headphone channels:

1. Press the Button labeled "Stereo". The button turns grey and a second channel strip opens with its own gain control.

Press the "Stereo" button again to create a stereo channel.




Any previously created gain offset between left and right channel will be ignored when joining the channels to a stereo group.

In addition, the overall output level can be adjusted between +4 and +19 dBu for each phones output (+10 dBu and +25 dBu in balanced mode)

10.2.5. Muting the Phones Output

To mute the phones output:

1. Press the **PH 1/2** or **PH 3/4** button next to the corresponding phones output.
2. Confirm the current output gain by pressing the encoder once.
3. Turn the encoder to highlight the MUTE button.



4. Press the mute button. It turns red to symbolize that the phones are muted.



To mute the phones output using the web remote:

1. Press the mute button in the Phones output channel.

10.2.6. Using Phones Out as a Balanced Line Output

The headphone output can operate as a mono balanced line level output. This may for example be useful when an active talkback speaker with symmetrical input is connected to the 12Mic.

To activate balanced output mode on the device:

1. Press the **PH 1/2** or **PH 3/4** button to access phones output settings.
2. Confirm the current gain by pressing the encoder, then turn the encoder to navigate to "Mode".
3. Push and turn the encoder to activate "balanced", push again to confirm. The channel that was routed to the left phones output will now be applied to both tip and ring of a TRS connector, the phase being inverted on the ring.

To toggle balanced output mode using the web remote:

1. Open the phones output channel.



2. Press the **BAL** button to switch the channel to balanced out. The channel that was routed to the left phones output will now be applied to both tip and ring of a TRS connector, the phase being inverted on the ring.

10.3. MADI Outputs

The MADI outputs of the M-1620 Pro are always active. If no routing is configured, an empty stream is sent that can be used for clocking. The state without routing is represented with a light-green **Status Indicator**.


For instructions on how to create a routing to the MADI Output, see [Section 10.1, "Routing Signals to the Outputs"](#).

10.3.1. Setting the Output Channel Format and Frame Pattern

Depending on the requirements of the receiver, it is possible to change the channel format and frame pattern of the outgoing MADI streams.

To change the channel format of both MADI outputs on the device:

1. Go to one of the **MADI** tabs in the **OUTPUT** section.



2. Toggle the switch to **56Ch** or **64Ch** to adjust number of output channels.

To change the channel format of both MADI outputs using the web remote:

1. Open either MADI output port in the routing view.
2. Select the channel mode from the corresponding menu.



56Ch and 64Ch format correspond to 28/32 channels at double speed, and to 14/16 channels at quad speed.

To change the frame pattern of both MADI outputs on the device:

1. Go to one of the **MADI** tabs in the **OUTPUT** section.
2. Toggle the switch for 96k to use the 96k frame at 88.2 kHz and 96 kHz.

To change the frame pattern of both MADI outputs using the web remote:

1. Open either MADI output port in the routing view.
2. Select the frame format from the corresponding menu.



The 96k frame setting affects outgoing MADI signals at sample rates 88.2 kHz and 96 kHz. At other sample rates, the setting is not relevant and does not affect the outgoing signal.



It is not possible to select separate settings for each MADI port. Both ports will be

affected regardless which output tab is used to change the setting.

10.3.2. MADI Daisy Chains

MADI is a uni-directional protocol with a fixed number of channels. When more than two MADI devices are connected, a serial connection is required. This is also referred to as a "daisy chain". The output of the first device is connected to the input of the second device, the output of the second device to the input of third device, and so on, until the signal is plugged into the input of the first device.

In a daisy chain, each device must be configured to pass on the *relevant* audio channels of its MADI input (the preceding devices) to the MADI output (the following device). Otherwise, each device would create a new MADI signal and not pass on audio from the devices that are connected to it.



While many RME devices pass on MADI signals automatically, the M-1620 Pro must be explicitly configured to do so.

In order to pass on signals, configure the output routing of the required output port to pass on the signal from the MADI input port.



The latency of the MADI I/O is four samples.



The M-1620 Pro creates an entirely new output signal and does not pass on any embedded information. One exception are SysEx messages (incl. MIDI over MADI) that are passed on between the ports chosen in the [MIDI Remote settings](#).

10.3.3. MADI Port Mirroring

A redundant MADI connection protects from loss of audio in case of a single cable failure. To achieve redundancy, the receiver must support MADI redundancy. The sender must send two identical MADI signals on two outputs, usually the coaxial and optical ports.

The M-1620 Pro features independent routing for both MADI output ports. For this reason, a "mirroring" of the signal must be manually created. In order to do this, the routing of the two MADI outputs should be configured to contain the same routing.



The receiving device usually ignores the audio contents of the two MADI signals. Therefore, the redundancy may appear to be set up even though the M-1620 Pro sends different audio signals on both ports. Always ensure that the routing is correct for both output ports.

10.4. AVB Output Streams

The AVB streams *leaving* the M-1620 Pro are described as "output streams". In this case, the device acts as a **talker**. The talker defines the *presentation time* and therefore the latency across the network. This is set per default to **2 ms**. See [Section 5.4, "AVB Network Latency"](#) for details on AVB latency.

The output streams of the M-1620 Pro are by default **empty**, containing a clock signal but no audio signal. To send audio with AVB, a **routing** must be created for each outgoing stream.

To establish a connection between a talker and a listener, an **ATDECC controller** is required. The M-1620 Pro does not include an ATDECC controller.

Outgoing AVB streams are monitored by the device. The possible states of the color indicator bar of

each output stream are the following:


| Description | Indicator | Possible solution |
|------------------------|------------|---|
| Disabled | grey | Create routing |
| Disabled | orange | Create connection with ATDECC controller |
| Streaming/Transmitting | green | |
| SR mismatch | red | Verify that the sample rates of talker and listener are identical |
| Waiting | yellow ... | Wait for listener to be ready |
| Listener Fail | red | Verify proper listener configuration |
| No Bandwidth | red | Use faster network speed (1 GBit/s instead of 100 MBit/s) |
| Domain Boundary | red | Reconnect all devices and reboot switch |
| Internal Error | red | Reboot device |

10.4.1. Change AVB Output Stream Size and Format


Each of the eight outgoing AVB streams can have a size of 1-8, 12 or 16 channels in AM824 and AAF stream formats. The additional CRF Stream's format cannot be changed.

To change the amount of channels and its format in the outgoing AVB stream on the device:

1. Open one of the eight **AVB** tabs in the **OUTPUT** section.



2. Move the cursor to highlight the current AVB stream **size** and press the encoder.



3. Rotate the encoder to configure a new stream size and stream format and confirm by pressing the encoder again.

To change the amount of channels of the outgoing AVB streams:

1. Connect the device by USB or network cable and open the [Section 8.5.1, "Finding the Device on a Network"](#).
2. Open one of the outgoing AVB Ports.
3. Select the configuration ⚙ within the AVB output port to open the outgoing stream settings.
4. Adjust output streams as necessary and click **OK**.



Changing a stream size briefly interrupts all outgoing AVB streams.

10.4.2. Adjusting the Network Latency


The default presentation time offset of 2 ms for outgoing streams can be changed when lower latencies are required.



Reducing the offset to a lower value can prevent audio to be played out depending on the network.

This setting can only be accessed on the web remote (see [Section 8.5.1, "Finding the Device on a Network"](#)), where it can be found in the outgoing stream settings.

To adjust the presentation time offset:

1. Connect the device by USB or network cable and open the [Section 8.5.1, "Finding the Device on a Network"](#).
2. Open one of the outgoing AVB Ports.
3. Select the configuration  within the AVB output port to open the outgoing stream settings.
4. Choose the desired units: ms, μ s, ns, or samples (default).
5. Adjust the presentation time offset by entering values for each stream or for all streams at once and press **OK**.

AVB Output Stream Formats

| | Channels | Format | PTO | | Stream ID | Destination | Stream State |
|--------------|----------|--------|-----|-----|-------------------------|-------------------|--------------|
| Stream 1 | 8 | AAF | 192 | smp | 48:0b:b2:d0:0a:d4:00:00 | 91:e0:f0:00:d7:08 | Disabled |
| Stream 2 | 8 | AAF | 192 | smp | 48:0b:b2:d0:0a:d4:00:01 | 91:e0:f0:00:d7:09 | Disabled |
| Stream 3 | 8 | AAF | 192 | smp | 48:0b:b2:d0:0a:d4:00:02 | 91:e0:f0:00:d7:0a | Disabled |
| Stream 4 | 8 | AAF | 192 | smp | 48:0b:b2:d0:0a:d4:00:03 | 91:e0:f0:00:d7:0b | Disabled |
| Stream 5 | 8 | AAF | 192 | smp | 48:0b:b2:d0:0a:d4:00:04 | 91:e0:f0:00:d7:0c | Disabled |
| Stream 6 | 8 | AAF | 192 | smp | 48:0b:b2:d0:0a:d4:00:05 | 91:e0:f0:00:d7:0d | Disabled |
| Stream 7 | 8 | AAF | 192 | smp | 48:0b:b2:d0:0a:d4:00:06 | 91:e0:f0:00:d7:0e | Disabled |
| Stream 8 | 8 | AAF | 192 | smp | 48:0b:b2:d0:0a:d4:00:07 | 91:e0:f0:00:d7:0f | Disabled |
| Clock Stream | | | 192 | smp | 48:0b:b2:d0:0a:d4:00:08 | 91:e0:f0:00:d7:10 | Disabled |

Channel Count

8 [Set all](#)

Format

AAF [Set all](#)

Presentation Time Offset (PTO)

2 switches

29 [Set all](#)

Time Unit

samples

Cancel

OK



Values will be rounded to the nearest 100ns.



Changing the presentation time offset briefly interrupts all incoming and outgoing AVB streams.

10.5. ADAT Outputs

The ADAT outputs of the M-1620 Pro are always active and can therefore be used as a clock source

for other devices with corresponding inputs.

On a new device, with preset 1 loaded and not modified, the analog input channels 1-8 are routed to ADAT port 1, and channels 9-12 are sent to ADAT port 2.

To create or modify routings, see [How to Create an Output Routing](#).

The routing to ADAT outputs is saved per port. As a result, changing the sampling rate to double or quad speed temporarily hides the channels that cannot be transmitted for each output port, but restores their routing once the sampling rate is reduced in the clock settings.



At 44.1 and 48 kHz, a maximum of eight channels can be transmitted per port. This amount is reduced to four channels at 88.2 and 96 kHz (double speed), and to two channels at 176.4 and 192 kHz (quad speed) respectively.




there are no settings available or necessary for the ADAT outputs.

11. CLOCK Section

The **CLOCK** section is used to inspect and configure the clock source and sample rate of the M-1620 Pro.

Web remote



- 1 Clock Section
- 2 Selected Reference Clock
- 3 Status Indicator
- 4 Current Clock Reference and Rate
- 5 Sample Rate Selection
- 6 Word Clock Output Single Speed Setting
- 7 Set as Clock Reference

11.1. Clock Status

The clock of all digital inputs is continuously monitored with **SyncCheck™** and shown in the **CLOCK** section. A **warning (red)** occurs when the chosen clock source fails. A **caution (orange)** is displayed when a routed signal is out of sync. A **notice (light yellow)** is displayed when a signal is present/locked, but not in sync and not routed. A **good notice (light green)** is displayed when a signal is present and in sync, but not routed or chosen as clock source. A **good confirmation (green)** is shown when the signal is present and either chosen as source or routed and in sync.



A **warning** causes the CLOCK section to turn red, and the selected source generating the issue is displayed on the standby screen.

11.2. Clock Reference

In its default state, the M-1620 Pro uses an internal clock signal ("*leader*"/"*master*"). This means that any connected device must synchronize to it ("*follower*"/"*slave*").

Alternatively, one of the digital inputs (word clock, MADI optical, MADI coaxial, and each of the four AVB streams) can be chosen as clock reference. This activates **SteadyClock™ FS**, a technology that extracts a low jitter clock signal from the incoming signal.

Intelligent Clock Control (ICC) automatically changes the clock source when the chosen clock reference input does not detect a valid signal. Using the feedback of SyncCheck™, the M-1620 Pro will change to another source signal that can be used as a clock reference. If no other source is available, the device will fall back to its internal clock until the chosen clock reference has recovered. Due to the excellent performance of RME's clock technology, disconnection and re-connection of a

clock reference is likely to be performed without losing a sample in the outgoing audio signal.




ICC switches the clock source between word clock, MADI optical, MADI coaxial, and internal, seamlessly, when the MADI optical, coaxial or word clock inputs fail and the other port is locked - or to internal. ICC will not fall back to an AVB sync source and also will not affect a chosen AVB reference clock.

11.2.1. Selecting a Clock Reference

To configure the clock reference on the device:


1. Enter the **CLOCK** section. The cursor highlights the currently selected clock reference.



2. Push the encoder. Two blue arrows are shown to indicate that the encoder can now be used to change the current setting.
3. Rotate the encoder until the preferred clock source is shown.
4. Push the encoder again to activate the setting.

To configure the clock reference on the web remote:

1. In the Clock panel, locate the button for the corresponding clock and click it.
2. Within the dropdown, press **Set as Clock Source**.



11.3. Sample Rates Overview

The M-1620 Pro supports the following sample rates:

Supported sample rates

| | |
|--------------|--------------------|
| Single speed | 44.1 kHz, 48 kHz |
| Double speed | 88.2 kHz, 96 kHz |
| Quad speed | 176.4 kHz, 192 kHz |

If the device is clock reference (*"leader"/"master"*), these rates always correspond to the actual sample rate used.

11.3.1. Following an External Clock Reference

When the device is synchronized to an external clock reference (*"follower"/"slave"*), certain deviations are automatically accepted to avoid interruption of the outgoing audio signal when the sample rate changes. This is called Intelligent Clock Control (ICC). It also handles deriving a sample rate of double or quad speed based on an incoming rate.

Intelligent Clock Control (ICC)

| Input | Clock at input | Selected Sample Rate | Resulting Sample Rate |
|------------|-------------------|----------------------|-----------------------|
| MADI | 44.1 | 44.1 | 44.1 |
| MADI | 44.1 | 48 | 44.1 with warning |
| MADI | 44.1 | 88.2 | 88.2 |
| MADI | 44.1 | 96 | 88.2 with warning |
| MADI | 44.1 | 176.4 | 176.4 |
| MADI | 44.1 | 192 | 176.4 with warning |
| MADI | 48 | 44.1 | 48 with warning |
| MADI | 48 | 48 | 48 |
| MADI | 48 | 88.2 | 96 with warning |
| MADI | 48 | 96 | 96 |
| MADI | 48 | 176.4 | 192 with warning |
| MADI | 48 | 192 | 192 |
| MADI 96k | 88.2 | 44.1 | warning (no sync) |
| MADI 96k | 88.2 | 48 | warning (no sync) |
| MADI 96k | 88.2 | 88.2 | 88.2 |
| MADI 96k | 88.2 | 96 | 88.2 with warning |
| MADI 96k | 88.2 | 176.4 | warning (no sync) |
| MADI 96k | 88.2 | 192 | warning (no sync) |
| MADI 96k | 96 | 44.1 | warning (no sync) |
| MADI 96k | 96 | 48 | warning (no sync) |
| MADI 96k | 96 | 88.2 | 96 with warning |
| MADI 96k | 96 | 96 | 96 |
| MADI 96k | 96 | 176.4 | warning (no sync) |
| MADI 96k | 96 | 192 | warning (no sync) |
| Word Clock | 44.1 | 44.1 | 44.1 |
| Word Clock | 44.1 | 48 | 44.1 (with warning) |
| Word Clock | 44.1, 88.2 | 88.2 | 88.2 |
| Word Clock | 44.1, 88.2 | 96 | 88.2 with warning |
| Word Clock | 44.1, 88.2, 176.4 | 176.4 | 176.4 |
| Word Clock | 44.1, 88.2, 176.4 | 192 | 176.4 with warning |
| Word Clock | 48 | 44.1 | 48 with warning |
| Word Clock | 48 | 48 | 48 |
| Word Clock | 48, 96 | 88.2 | 96 with warning |
| Word Clock | 48, 96 | 96 | 96 |
| Word Clock | 48, 96, 192 | 176.4 | 192 with warning |
| Word Clock | 48, 96, 192 | 192 | 192 |

There is no ICC mechanism necessary for AVB; the device will always use the exact clock from the corresponding AVB stream.



It is not recommended to synchronize devices with a higher sample rate than the current sample rate, because two devices could choose different edges of the incoming clock signal.



ICC does not affect outgoing AVB streams. Outgoing AVB streams will always correspond to the sample rate set in the **CLOCK** section. If the reference clock changes its frequency, outgoing AVB streams will be interrupted.

11.3.2. Number of Channels

The supported number of channels per port or stream at different sample rates is shown in the following table.

Supported number of audio channels per stream/port and direction at different sample rates

| | 44.1 kHz | 48 kHz | 88.2 kHz | 96 kHz | 176.4 kHz | 192 kHz |
|-------------------|----------|--------|----------|--------|-----------|---------|
| MADI 56 Ch | 56 | 56 | 28 | 28 | 14 | 14 |
| MADI 64 Ch | 64 | 64 | 32 | 32 | 16 | 16 |
| MADI 56 Ch + 96k | --- | --- | 28 | 28 | --- | --- |
| MADI 64 Ch + 96k | --- | --- | 32 | 32 | --- | --- |
| AVB 1-8 Ch stream | 1-8 | 1-8 | 1-8 | 1-8 | 1-8 | 1-8 |
| AVB 12 Ch stream | 12 | 12 | 12 | 12 | --- | --- |
| AVB 16 Ch stream | 16 | 16 | --- | --- | --- | --- |




Since there are two independent MADI ports, the total supported number of channels can be multiplied by two. Since there are eight independent AVB streams, the total supported number of channels can be multiplied by eight. The analog channel count remains identical at all sample rates.

11.3.3. Selecting a Sample Rate

To configure the device sample rate on the device:

1. Enter the **CLOCK** section.



2. Rotate the encoder to highlight the current sample rate.
3. Push the encoder. Two blue arrows will appear to indicate that the encoder can now be used to

change the current setting.

4. Rotate the encoder until the preferred sample rate is shown.
5. Push the encoder again to activate the setting.

To configure the device sample rate on the web remote:

1. Locate the **Select sample rate** drop down menu in the **CLOCK** section.
2. Select a sample rate from the drop down menu. The new rate is applied immediately.

11.3.4. Effects of Sample Rate Changes on Existing Routing

The M-1620 Pro saves one routing table per preset, regardless of sample rate. A change of sample rate or MADI frame mode can reduce the number of input and output channels available for routing. This does not alter the routing table. Any existing routing is hidden until another change of sample rate re-enables the channels.

Example:

A routing is created at 96 kHz with 32 channels, sending the MADI coaxial Input 1-32 to optical MADI Output 1-32. If the sample rate is now changed to 176.4 kHz and the 56 Ch frame is activated, only the first 14 channels of MADI coaxial input are routed to the optical output. Switching the sample rate to 44.1 or 48 kHz will reveal the previous routing for 32 channels.


11.4. Set Word Clock Output to Single Speed

At sample rates > 48 kHz, it may be necessary to synchronize two devices with a fraction of the actual sample rate:

| Sample Rate | Word Clock Full Speed (default) | Word Clock Single Speed (option) |
|-------------|---------------------------------|----------------------------------|
| 88.2 kHz | 88.2 kHz | 44.1 kHz |
| 96 kHz | 96 kHz | 48 kHz |
| 176.4 kHz | 176.4 kHz | 44.1 kHz |
| 192 kHz | 192 kHz | 48 kHz |

To set the Word Clock output to single speed on the device:

1. Open the **CLOCK** section.



2. Move the cursor onto the toggle switch **Word Out Single** and push the encoder to change the value.

To set the Word Clock output to single speed on the web remote:

1. Locate the **CLOCK** section.
2. Move the cursor onto the **Word Out Single** switch and push the encoder to change the value.

12. Annex

Trademarks and Copyright

All trademarks, registered or otherwise, are the property of their respective owners.

RME is a registered trademark of RME Intelligent Audio Solutions.

SyncCheck, SteadyClock, ICC, Intelligent Clock Control and Digiface are trademarks of RME Intelligent Audio Solutions.

Microsoft, Windows, Windows 10/11 are registered trademarks of Microsoft Corp.

Apple, iOS, iPad and macOS are registered trademarks of Apple Inc.

ADAT® is a registered trademark of Alesis Corp.

Copyright © 2025 m2lab Ltd.



This manual is licensed under a [Creative Commons Attribution-NonCommercial-NoDerivatives 4.0 International License](https://creativecommons.org/licenses/by-nc-nd/4.0/).

12.1. Glossary

96k frame

MADI sources with a sample rate of 88.2kHz or 96kHz can be configured to use the so-called **96k frame**. If this frame is used, a sample rate of 88.2 or 96 kHz can be detected on the receiver side automatically. When it is not used, or when higher sample rates are used, the receiver must always be configured to the correct factor (x2, x4) since there is no other mechanism in MADI that allows automatic detection.

AVB

Audio Video Bridging (AVB) is a common name for the set of technical standards developed by the Institute of Electrical and Electronics Engineers (IEEE) Audio Video Bridging Task Group of the IEEE 802.1 standards committee.

ATDECC

IEEE standard for device discovery and control. A protocol that is used by manufacturers to control various settings of AVB endpoints.

ATDECC Controller

A software that discovers AVB entities and allows the user to access their settings and connect them. Different ATDECC Controllers from different vendors can be used at the same time in the same network.

AVB talker

An AVB endpoint that streams audio to one or more listeners.

AVB listener

An AVB endpoint that receives an audio stream from a talker.

Double speed

A sampling rate of 88.2 kHz or 96 kHz (compare [single speed](#) and [quad speed](#))

DHCP server

A DHCP Server hands out IP addresses to network devices. Every consumer oriented WiFi Router has a default DHCP Server handing out private addresses, usually 192.168.0.x. The IP address of a network device must be known in order to communicate with it on Layer 3.

MADI

Multichannel Digital Audio Interface as defined in the AES 10 standard. Used to receive and transmit up to 64 uncompressed audio channels over coaxial or fibre optic connection.

Quad speed

A sampling rate of 176.4 or 192 kHz (compare [single speed](#) and [double speed](#)).

Single speed

A sampling rate of 44.1 kHz or 48 kHz (compare [double speed](#) and [quad speed](#)).

Word Clock

An electrical square wave signal transported over coaxial 75 Ohm terminated cables. It is used to synchronize the receiving device (slave, word clock input) to the sending device (master, word clock output).

12.2. Regulatory Compliance

12.2.1. CE Compliance

This device has been tested and found to comply with the limits of the European Council Directive on the approximation of the laws of the member states relating to electromagnetic compatibility according to RL2014/30/EU, and European Low Voltage Directive RL2014/35/EU.

12.2.2. FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.

Responsible Party in USA: Synthax United States, 6600 NW 16th Street, Suite 10, Ft Lauderdale, FL 33313 T.:754.206.4220

Trade Name: RME, Model Number: M-1620 Pro

12.2.3. Note on Disposal

According to the guide line RL2002/96/EG (WEEE – Directive on Waste Electrical and Electronic Equipment), valid for all european countries, this product has to be recycled at the end of its lifetime. In case a disposal of electronic waste is not possible, the recycling can also be done by Scheck Audio GmbH, the manufacturer of this device.

For this the device has to be sent free to the door to:

Scheck Audio GmbH, 3. Industriestr. 5, 68804 Altlussheim, Germany.

Shipments not prepaid will be rejected and returned on the original sender's costs.